

85 Degree - Lindab pipe measure guide

In situations with large overhangs resulting in the gooseneck being too low, or where extra clearance is required above a door or window, the 85 Degree elbow is a good option.

Cut dimensions for goosenecks are easily calculated by taking a measurement from the bottom back edge of the outlet OMV or OK to the wall.

85 Degree elbow


Gooseneck dim = (measurement minus 9-1/4") multiplied by 1.004

Vertical distance below outlet = (measurement minus 9-1/4") multiplied by .0875, plus 8-7/8"

To offset two vertical pipes, the joining pipe is calculated as;

(Pipe offset distance minus 8-1/8") multiplied by 1.004

The chart below shows Gooseneck and wall distance for Soffit measures from 12 to 60 inches.



Soffit	Pipe	Wall
12	2-3/4	9-1/8
14	4-3/4	9-1/4
16	6-3/4	9-1/2
18	8-3/4	9-3/4
20	10-3/4	9-7/8
22	12-3/4	10
24	14-3/4	10-1/4
26	16-3/4	10-3/8
28	18-3/4	10-1/2
30	20-3/4	10-3/4
32	22-3/4	10-7/8
34	24-3/4	11-1/8
36	26-3/4	11-1/4
38	28-3/4	11-1/2
40	30-3/4	11-5/8
42	32-7/8	11-3/4
44	34-7/8	12
46	36-7/8	12-1/8
48	38-7/8	12-3/8
50	40-7/8	12-1/2
52	42-7/8	12-5/8
54	44-7/8	12-7/8
56	46-7/8	13
58	48-7/8	13-1/4
60	50-7/8	13-3/8